

## Datasheet

SureCross® Wireless Q45 Sensor Nodes combine the best of Banner's flexible Q45 sensor family with its reliable, field-proven, SureCross wireless architecture to solve new classes of applications limited only by the user's imagination. Containing a variety of sensor models, a radio, and internal battery supply, this product line is truly plug and play.



In opposed-mode sensing, the sensor's emitter and receiver are housed in two separate units. The emitter is placed opposite the receiver, so that the light beam goes directly from the emitter to the receiver. An object is detected when it breaks the working part of the beam, known as the effective beam.

### Available Models

- DX80N2Q45E (Emitter) and DX80N2Q45R (Receiver)



### WARNING: Not To Be Used for Personnel Protection

Never use this device as a sensing device for personnel protection. Doing so could lead to serious injury or death. This device does not include the self-checking redundant circuitry necessary to allow its use in personnel safety applications. A sensor failure or malfunction can cause either an energized or de-energized sensor output condition.


## Storage Mode for the Wireless Q45 Sensors

While in storage mode, the Wireless Q45 Sensor's radio does not operate. All Wireless Q45 Sensors ship from the factory in storage mode to conserve the battery. To wake the device, press and hold the button for five seconds. To put any Wireless Q45 Sensor into storage mode, press and hold the button for five seconds. The Wireless Q45 Sensor is in storage mode when the LEDs stop blinking.

## Optical Alignment Mode (Opposed)

The Wireless Q45 Sensor Node enters and remains in optical alignment mode for 15 minutes after the button is pushed, after the Wireless Q45 Sensor Node exits binding mode, or after the Q45 is powered up (battery replaced). During this alignment mode, the receiver sensor's amber LED lights up when it does not see the emitter.

After 15 minutes, the Wireless Q45 Sensor Node automatically exits optical alignment mode and begins normal operation. After the sensor begins normal operation, the amber sensor state LED is inactive. To exit alignment mode earlier, click the button five times.




## Modbus Register Table

| I/O # | Modbus Holding Register |                  | I/O Type       | I/O Range  |            | Holding Register Representation |             |
|-------|-------------------------|------------------|----------------|------------|------------|---------------------------------|-------------|
|       | Gateway                 | Any Node         |                | Min. Value | Max. Value | Min. (Dec.)                     | Max. (Dec.) |
| 1     | 1                       | 1 + (Node# × 16) | Sensor IN 1    | 0          | 1          | 0                               | 1           |
|       |                         | ...              |                |            |            |                                 |             |
| 7     | 7                       | 7 + (Node# × 16) | Reserved       |            |            |                                 |             |
| 8     | 8                       | 8 + (Node# × 16) | Device Message |            |            |                                 |             |
|       |                         | ...              |                |            |            |                                 |             |



| I/O # | Modbus Holding Register |                   | I/O Type        | I/O Range  |            | Holding Register Representation |             |
|-------|-------------------------|-------------------|-----------------|------------|------------|---------------------------------|-------------|
|       | Gateway                 | Any Node          |                 | Min. Value | Max. Value | Min. (Dec.)                     | Max. (Dec.) |
| 15    | 15                      | 15 + (Node# × 16) | Control Message |            |            |                                 |             |
| 16    | 16                      | 16 + (Node# × 16) | Reserved        |            |            |                                 |             |

## Button and LEDs




- 1 Button
- 2 Green LED (flashing) indicates a good radio link with the Gateway.
- 3 Red LED (flashing) indicates a radio link error with the Gateway.
- 4 Alignment or Test Mode: the amber LED indicates sensor function (optical sensor models) or when input 1 is active (dry contact models). The amber LED is not used during normal operation.
- 5 Excess gain potentiometer. Turn clockwise to increase the gain.

## Replacing the Batteries

To replace the lithium "AA" cell battery, follow these steps.

As with all batteries, these are a fire, explosion, and severe burn hazard. Do not burn or expose them to high temperatures. Do not recharge, crush, disassemble, or expose the contents to water. Properly dispose of used batteries according to local regulations by taking it to a hazardous waste collection site, an e-waste disposal center, or other facility qualified to accept lithium batteries.



1. Lift the plastic cover.
2. Slide the board containing the batteries out of the Q45 housing.
3. Remove the discharged batteries and replace with new batteries. Use two 3.6 V AA lithium batteries, such as Xeno's XL-60F or equivalent.
4. Verify the battery's positive and negative terminals align to the positive and negative terminals of the battery holder mounted within the case. Caution: There is a risk of explosion if the battery is replaced incorrectly.
5. Slide the board containing the new batteries back into the Q45 housing.

Replacement battery model number: BWA-BATT-006. For pricing and availability, contact Banner Engineering.

## Bind the Q45s to the Gateway and Assign the Node Address

Before beginning the binding procedure, apply power to all the devices.

1. Enter binding mode on the Gateway.
  - For -B2Q board modules, triple-click the button.
  - For -Q and -QC models, triple-click button 2.

On the board modules, the green and red LED flashes. On the -Q and -QC Gateway models, both LEDs flash red.

2. Assign the Q45 a Node address using the Gateway's rotary dials. Use the left rotary dial for the left digit and the right rotary dial for the right digit. For example, to assign your Q45 to Node 01, set the left dial to 0 and the right dial to 1.

Valid Node addresses are 01 through 47.

3. Loosen the clamp plate on the top of the Wireless Q45 Sensor and lift the cover.

4. Enter binding mode on the Wireless Q45 Sensor by triple-clicking the button. For the opposed mode sensor, the button is on the receiver.  
The red and green LEDs flash alternately and the sensor searches for a Gateway in binding mode. After the Q45 is bound, the LEDs stay solid momentarily, then they flash together four times. The Q45 exits binding mode.
5. Label the sensor with the Q45's Node address number and place the sticker on the Wireless Q45 Sensor.
6. Repeat steps 2 through 5 for as many Wireless Q45 Sensors as are needed for your network.
7. After binding all Wireless Q45 Sensors, exit binding mode on the Gateway.
  - For -B2Q board modules, double-click the button.
  - For -Q and -QC models, double-click button 2.

For Gateways with LCDs, after binding your Wireless Q45 Sensors to the Gateway, make note of the binding code displayed under the Gateway's \*DVCFG menu, XADR submenu on the LCD. Knowing the binding code prevents having to re-bind all Q45s if your Gateway is ever replaced.

## Specifications

The following specifications refer to both the radio and the wireless sensor.

### Range

2.4 GHz: Up to 1000 m (3280 ft) with line of sight<sup>1</sup>

### Transmit Power

2.4 GHz: 65 mW EIRP

### 2.4 GHz Compliance

FCC ID UE300DX80-2400 - This device complies with FCC Part 15, Subpart C, 15.247

ETSI/EN: In accordance with EN 300 328: V1.7.1 (2006-05)

IC: 7044A-DX8024

### Spread Spectrum Technology

FHSS (Frequency Hopping Spread Spectrum)

### Construction

Molded reinforced thermoplastic polyester housing, oring-sealed transparent Lexan® cover, molded acrylic lenses, and stainless steel hardware. Q45s are designed to withstand 1200 psi washdown.

### Indicators

Red and green LEDs (for radio function); amber LED (only for alignment mode)

### Typical Battery Life

Up to 2 years, typical

A typical battery life assumes an average of 10 seconds between sensor changes of state and the default 62.5 millisecond sample rate.

### Default Sensing Interval

62.5 milliseconds

### Report Rate

On Change of State

### Optical Sensing Range

Up to 30 m (100 ft) depending on Excess Gain requirements

### Adjustments


Multi-turn sensitivity control (allows precise sensitivity setting; turn clockwise to increase gain).

### Environmental Rating

NEMA 6P, IEC IP67

### Operating Conditions

-40 °C to +70 °C (-40 °F to +158 °F); 90% relative humidity at 50 °C (non-condensing)



## Warnings

Violating Warnings. The manufacturer does not take responsibility for the violation of any warning listed in this document. Make no modifications to this product; any modifications to this product not expressly approved by Banner Engineering could void the user's authority to operate the product. All specifications published in this document are

<sup>1</sup> The actual radio range significantly decreases without line of sight. Always verify your wireless network's range by running a site survey.

subject to change; Banner reserves the right to modify product specifications or update documentation at any time. For the most recent version of any documentation, refer to: [www.bannerengineering.com](http://www.bannerengineering.com). © 2006-2014 Banner Engineering Corp. All rights reserved.

## Exporting SureCross Radios

Exporting SureCross Radios. It is our intent to fully comply with all national and regional regulations regarding radio frequency emissions. Customers who want to re-export this product to a country other than that to which it was sold must ensure the device is approved in the destination country. A list of approved countries appears in the *Radio Certifications* section of the product manual. The SureCross wireless products were certified for use in these countries using the antenna that ships with the product. When using other antennas, verify you are not exceeding the transmit power levels allowed by local governing agencies. Consult with Banner Engineering Corp. if the destination country is not on this list.

## Banner Engineering Corp Limited Warranty

Banner Engineering Corp. warrants its products to be free from defects in material and workmanship for one year following the date of shipment. Banner Engineering Corp. will repair or replace, free of charge, any product of its manufacture which, at the time it is returned to the factory, is found to have been defective during the warranty period. This warranty does not cover damage or liability for misuse, abuse, or the improper application or installation of the Banner product.

THIS LIMITED WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES WHETHER EXPRESS OR IMPLIED (INCLUDING, WITHOUT LIMITATION, ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE), AND WHETHER ARISING UNDER COURSE OF PERFORMANCE, COURSE OF DEALING OR TRADE USAGE.

This Warranty is exclusive and limited to repair or, at the discretion of Banner Engineering Corp., replacement. IN NO EVENT SHALL BANNER ENGINEERING CORP. BE LIABLE TO BUYER OR ANY OTHER PERSON OR ENTITY FOR ANY EXTRA COSTS, EXPENSES, LOSSES, LOSS OF PROFITS, OR ANY INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES RESULTING FROM ANY PRODUCT DEFECT OR FROM THE USE OR INABILITY TO USE THE PRODUCT, WHETHER ARISING IN CONTRACT OR WARRANTY, STATUTE, TORT, STRICT LIABILITY, NEGLIGENCE, OR OTHERWISE.

Banner Engineering Corp. reserves the right to change, modify or improve the design of the product without assuming any obligations or liabilities relating to any product previously manufactured by Banner Engineering Corp.